

Asterix category 063 - Sensor Status Reports

category: 063

edition: 1.6

date: 2020-08-04

Preamble

Surveillance data exchange.

Description of standard data items

I063/010 - Data Source Identifier

Definition: Identification of the radar station from which the data are received.

Structure:

I063/010/SAC - System Area Code

- 8 bits [.]
- raw value

I063/010/SIC - System Identification Code

- 8 bits [.]
- raw value

Note: The defined SACs are on the EUROCONTROL ASTERIX website (www.eurocontrol.int/asterix)

I063/015 - Service Identification

Definition: Identification of the service provided to one or more users.

Structure:

- 8 bits [.]
- raw value

The service identification is allocated by the SDPS

I063/030 - Time of Message

Definition: Absolute time stamping of the message, in the form of elapsed time since last midnight, expressed as UTC.

Structure:

- 24 bits [.]
- unsigned quantity
- unit: "s"
- $\text{LSB} = 1/2^7 \text{ s} \approx 7.81e - 3 \text{ s}$

The time of the day value is reset to zero at every midnight.

I063/050 - Sensor Identifier

Definition: Structure:

I063/050/SAC - System Area Code

- 8 bits [.]
- raw value

I063/050/SIC - System Identification Code

- 8 bits [.]
- raw value

- The up-to-date list of SACs is published on the EUROCONTROL Web Site (<http://www.eurocontrol.int/asterix>).
- If the SAC/SIC refers to an SDPS used as input, the respective sensor status information will be transmitted using the Reserved Expansion Field.

I063/060 - Sensor Configuration and Status

Definition: Configuration and status of the sensor

Structure:

Extended item.

I063/060/CON

- 2 bits [. .]
- values:
 - 0: Operational
 - 1: Degraded
 - 2: Initialization
 - 3: Not currently connected

I063/060/PSR

- 1 bit [.]
- values:
 - 0: PSR GO
 - 1: PSR NOGO

I063/060/SSR

- 1 bit [.]
- values:
 - 0: SSR GO
 - 1: SSR NOGO

I063/060/MDS

- 1 bit [.]
- values:
 - 0: MDS GO
 - 1: MDS NOGO

I063/060/ADS

- 1 bit [.]

- values:
 - 0: ADS GO
 - 1: ADS NOGO

I063/060/MLT

- 1 bit [.]
- values:
 - 0: MLT GO
 - 1: MLT NOGO

(FX)

- extension bit
 - 0: End of data item
 - 1: Extension into next extent

I063/060/OPS - *Operational Release Status of the System*

- 1 bit [.]
- values:
 - 0: System is released for operational use
 - 1: Operational use of System is inhibited

I063/060/ODP - *Data Processor Overload Indicator*

- 1 bit [.]
- values:
 - 0: Default, no overload
 - 1: Overload in DP

I063/060/OXT - *Transmission Subsystem Overload Status*

- 1 bit [.]
- values:
 - 0: Default, no overload
 - 1: Overload in transmission subsystem

I063/060/MSC - *Monitoring System Connected Status*

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I063/060/TSV - *Time Source Validity*

- 1 bit [.]
- values:
 - 0: Valid
 - 1: Invalid

I063/060/NPW - *No Plot Warning*

- 1 bit [.]
- values:
 - 0: Default (no meaning)
 - 1: No plots being received

I063/060/(spare)

- 1 bit [.]

(FX)

- extension bit
 - 0: End of data item
 - 1: Extension into next extent

1. GO/NOGO information from PSR, SSR, Mode S, ADS and MLT is derived from monosensor categories and has a meaning only for operational sensors, whereas (CON) is derived by the SDPS.
2. The information (OPS), (ODP), (OXT), (MSC) and (TSV) are only related to CNS/ATM Ground Station and are derived from monosensor category (ASTERIX Cat 023).

I063/070 - Time Stamping Bias

Definition: Plot Time stamping bias, in two's complement form

Structure:

- 16 bits [.....]
- signed quantity
- unit: "ms"
- LSB = 1 ms

I063/080 - SSR / Mode S Range Gain and Bias

Definition: SSR / Mode S Range Gain and Range Bias, in two's complement form.

Structure:

I063/080/SRG - Mode S Range Gain

- 16 bits [.....]
- signed quantity
- $LSB = 1/100000 \approx 1.00e - 5$

I063/080/SRB - Mode S Range Bias

- 16 bits [.....]
- signed quantity
- unit: "NM"
- $LSB = 1/2^7 \text{ NM} \approx 7.81e - 3 \text{ NM}$

Note:

The following formula is used to correct range:

$$\rho_{\text{corrected}} = \frac{\rho_{\text{measured}} - \text{range_bias}}{1 + \text{range_gain}}$$

I063/081 - SSR Mode S Azimuth Bias

Definition: SSR / Mode S Azimuth Bias, in two's complement form.

Structure:

- 16 bits [.]
- signed quantity
- unit: "°"
- $LSB = 360/2^{16} \text{ }^\circ \approx 5.49e - 3 \text{ }^\circ$

Note:

The following formula is used to correct azimuth:

$$\theta_{\text{corrected}} = \theta_{\text{measured}} - azimuth_bias$$

I063/090 - PSR Range Gain and Bias

Definition: PSR Range Gain and PSR Range Bias, in two's complement form.

Structure:

I063/090/PRG - PSR Range Gain

- 16 bits [.]
- signed quantity
- $LSB = 1/100000 \approx 1.00e - 5$

I063/090/PRB - PSR Range Bias

- 16 bits [.]
- signed quantity
- unit: "NM"
- $LSB = 1/2^7 \text{ NM} \approx 7.81e - 3 \text{ NM}$

Note:

The following formula is used to correct range:

$$\rho_{\text{corrected}} = \frac{\rho_{\text{measured}} - range_bias}{1 + range_gain}$$

I063/091 - PSR Azimuth Bias

Definition: PSR Azimuth Bias, in two's complement form.

Structure:

- 16 bits [.]
- signed quantity
- unit: "°"
- $LSB = 360/2^{16} \text{ }^\circ \approx 5.49e - 3 \text{ }^\circ$

Note:

The following formula is used to correct azimuth:

$$\theta_{\text{corrected}} = \theta_{\text{measured}} - azimuth_bias$$

I063/092 - PSR Elevation Bias

Definition: PSR Elevation Bias, in two's complement form.

Structure:

- 16 bits [.....]
- signed quantity
- unit: "°"
- $LSB = 360/2^{16} \text{ °} \approx 5.49e - 3 \text{ °}$

I063/RE - Reserved Expansion Field

Definition: Expansion

Structure:

Explicit item (RE)

I063/SP - Special Purpose Field

Definition: Special Purpose Field

Structure:

Explicit item (SP)

User Application Profile for Category 063

- (1) I063/010 - Data Source Identifier
- (2) I063/015 - Service Identification
- (3) I063/030 - Time of Message
- (4) I063/050 - Sensor Identifier
- (5) I063/060 - Sensor Configuration and Status
- (6) I063/070 - Time Stamping Bias
- (7) I063/080 - SSR / Mode S Range Gain and Bias
- (FX) - Field extension indicator
- (8) I063/081 - SSR Mode S Azimuth Bias
- (9) I063/090 - PSR Range Gain and Bias
- (10) I063/091 - PSR Azimuth Bias
- (11) I063/092 - PSR Elevation Bias
- (12) (spare)
- (13) I063/RE - Reserved Expansion Field
- (14) I063/SP - Special Purpose Field
- (FX) - Field extension indicator